

4 User Manual

The following instructions are for the default settings, and touch commands can be configured in the "XROUND MyTune" app.

LEFT earbud

Training Timer:

Tap and hold the LEFT touch panel for 15 seconds, and release it after you hear the earbuds beep. The timer will start counting down and beep again when the timer runs out. By default, the timer counts down from 30 seconds; you can set the duration of time in the "XROUND MyTune" app.

Volume Up:

Double-tap the LEFT touch panel.

Volume Down:

Triple-tap the LEFT touch panel.

RIGHT earbud

Switch to Active Noise Cancellation/Transparency Mode:

Tap and hold the RIGHT touch panel for 15 seconds to switch between Active Noise Cancellation and Transparency Mode. When you switch between two modes, you hear a chime and followed by a voice prompt "noise cancelling" or "ambient sound."

Play/Pause:

Double-tap the right earbud's touch panel to play or pause.

Voice Commands:

Triple-Tap the right earbud's touch panel to activate the Voice Commands.

5 Phone Calls

FORGE NC Supports Smart Phone Control

Answer Call Double-tap the touch panel on an incoming call.

Hang Up Double-tap the touch panel during a call.

Reject Triple-tap the touch panel on an incoming call.

Mute the Microphone Change the Gesture Control Settings in the MyTune APP.

Power off Call Rejected
Pairing Noise cancelling
Connected Ambient Sound
Pairing successful
Battery low

7 Reset settings to default

Place both earbuds into the charging case and long-press the function button for 10 seconds until the orange and white earbud LEDs flash simultaneously and the indicator of the charging case will flash 6 times, signaling the earbuds are reset.

※Do not remove the earbuds from the charging case when reset.

8 Charging Instructions

Charge the Earbuds: Place the earbuds back into the charging case to charge. Please wipe the sweat or stains on the charging terminal of the earbuds before charging.

Charge the Charging Case: Connect the Charging Case via Type-C cable to charge.

※FORGE NC's charging case supports wireless charging which meet Qi standard

Under the following circumstances, the charging case will display its battery level:

- When the charging case is opened
- When the earbuds are put back into the case
- When using a Type-C cable to charge

※The earbuds automatically power off and recharge in the charging case. LEDs of the earbuds become static orange while charging and will turn off when fully charged.

※The charging case can be charged separately. The indicator of the charging case will flash slowly while charging, and be off when fully charged. If the charging case is out of battery, it will not charge the earbuds.

Battery Level	Status of Battery Indicator
1~30%	Red light
30~65%	Orange light
65~100%	White light

Product Specifications

Bluetooth Version	Bluetooth® 5.2
Bluetooth Specification	Class 1
Wireless Range	15 m / Up to 80m in the barrier-free space
Bluetooth Codec	SBC、AAC、aptX™、aptX™ adaptive
Bluetooth Profile Support	AVRCP1.6 / HSP1.2 / HFP1.7 / A2DP1.3.1
Driver	7mm Titanium Coated Driver
Frequency Response	20 - 20,000 Hz
Driver Sensitivity	100 dB

Impedance	16 Ω
Microphone	4*MEMS (2*MEMS per side)
Battery Life	Playtime: 9 hours (Total 32 hours with the charging case) ※Battery life tested in 50% volume with AAC codec, ANC mode ON
Charging Case Type	Input : Type-C ※Support wireless charging meets Qi standard
Charging Time	Earbuds: 1.5 hour / Charging Case: 1.5 hour ※Empty-to-full time Fast Charging: Charge for 15 minutes, listen for 1 hour
IP Rating	IP67 (Earbuds)
Package Contents	FORGE NC True Wireless Earbuds * 1 Pair Charging Case * 1 pc Type-C Charging Cable - 1 pc Boom Tips * 3 pairs (S/M/L) Comfort Tips * 4 pairs (S/M/L/XL)

Safety Reminders

FORGE NC earbuds were developed to be safe, durable and effective. Please follow these guidelines to prolong the lifespan and ensure safety during use:

- Do not strike, throw, or subject the earbuds to severe physical shock.
- Store under dry and non-dusty conditions. Keep away from heat sources (Temperature < 51 °C).
- Listening at a high volume may affect your hearing. Please adjust the volume to the lowest acceptable volume.
- For road safety, do not use earbuds while driving or riding a bike.
- Do not use earbuds on railway level crossings, station platforms, crosswalks, and in construction sites.
- Clean the surface with a soft microfiber cloth.
- When the charging case is fully charged, disconnect the charging cable to prolong the battery life.
- Third-party accessories may not be compatible with your device. Use only trusted and certified chargers and accessories.
- The earbuds come with small accessories and parts. Keep out of reach of small children.
- Bluetooth signals may suffer from interference in the following environments:
 - Multiple Wi-Fi signals or Bluetooth connection in the same area
 - Airports, Express Railway, Metro, and similar areas with high electromagnetic interference

Battery Safety

- Use a charger that meets CE regulations for charging.
- Do not modify or disassemble the battery, insert foreign objects, immerse in water or other liquids to prevent battery leakages, overheating, fires or explosions.
- This device has a non-removable, built-in battery, do not disassemble the product or modify the battery. Some circuit failures may cause fire or electric shock.
- Dispose used batteries in accordance with local requirements and instructions.

Limited Warranty

Dear customer, Thank you for purchasing FORGE NC True Wireless Earbuds. We trust this product will fulfill all your needs and expectations. Should there be a problem, please read the warranty condition below: XROUND Inc. warrants this product for a period of one year from the date of original purchase or date of shipment of new, unused equipment.


Upon the expiration of the warranty period, XROUND no longer provides any repairs/replacements.

This warranty does not cover any defects, failures, or malfunctions caused by the following conditions:

- Damages to the device and various parts resulting from incorrect operation, abuse, and human negligence.
- Damage caused by force majeure or natural disasters.
- Improper repairs by unauthorized repair centers or personnel.

Other Important Information

- The warranty period is within one year from the date of purchase or the date of product shipment. Proof of purchase or warranty may be required for confirmation by customer service.
- If you purchase this product through a distribution channel platform other than the XROUND online official website, and there are product warranty/repair issues, please contact the distributor you purchased from for assistance. For distributor information, please refer to the official website.



2 充電ケース

- イヤホン充電端子
- ファンクションキー
- インジケーター
- Type-C 充電ポート

3 イヤーピース

コンフォートイヤーピース 全4組 S/M/L/XLの4サイズ

低音強化イヤーピース 全3組 S/M/Lの3サイズ

出荷時はMサイズが装着されています

4 イヤーフック

S/M/L/ツメなしの4セット、出荷の時はMサイズが装着されています。自分の耳にぴったりのサイズで装着してください。

FORGE NC 操作の流れ

1 電源をオン/オフにする

a.電源をオンにする ペアリングモードになり5分以内にデバイスと接続されない場合は、自動的に電源をオフになります。

充電ケースを開けると:自動的に電源が入ります。イヤホンのLEDランプが1秒間、白く点灯し、音声でPower onをお知らせします。

手で電源をオンにする:電源オフの状態、タッチパネルに約2秒間ロングタッチすると自動的に電源が入ります。

※イヤホンは電源が入ると、直近にペアリングしたデバイスに自動的に接続します。5秒以内に接続していない場合、イヤホンは自動でペアリングモードへ移行します。

b.電源をオフにする 自動で電源をオフにする:充電ケースに入ると、イヤホンのLEDランプがオレンジ色に点灯し、音声でPower offをお知らせして自動で電源がオフになり、充電がスタートします。

※自動での電源オン・オフは充電ケースの電池残量がある場合のみ機能します。

2 ペアリングする

イヤホンはデバイスをペアリングすることで、音楽再生や通話ができるようになります。

a. はじめてペアリングする

- イヤホンの充電端子に付いている絶縁テープを取り除き、充電ケースに入れてください。
- イヤホンを入れたらいったん充電ケースを閉じてください。再び充電ケースを開けると、イヤホンの電源が自動でオンになります。
- ケースをはじめて開けた状態のとき、FORGE NC は自動でペアリングモードになります。

b. 再ペアリングする

イヤホンを充電ケースに入れ、充電ケースのファンクションキーを約3秒間長押しすると、ペアリングモードへ移行します。

c. マルチポイント(最大2台)

※この機能を有効にする場合は、MyTuneアプリにて設定してください。

※はじめてのペアリングが完了後、イヤホンをケースに入れ、ファンクションキーを約3秒間長押しして、ペアリングモードへ移行します。その際第2台のデバイスのBluetooth機能をオンにし、イヤホンとのペアリングを行ってください。

※第2台とのペアリングが完成したら、もう一度ケースを開けてください。再び開けると、イヤホンは自動で2台のデバイスと同時接続します。

※ペアリングモードになると、イヤホンのLEDランプが白とオレンジが交互に点滅し、音声でPairingをお知らせします。

※ペアリングの際は必ずイヤホンを充電ケース内に入れて行ってください。

※デバイスとのペアリングは、充電ケースの電池残量がある場合にのみ機能します。

3 接続する

デバイスのBluetooth機能を有効にし、Bluetoothデバイスを検出できる状態にします。

iOS: デバイスのBluetooth機能を有効にし、Bluetoothデバイスを検出できる状態にします。

Android: 設定 > Bluetoothをオンにする > Bluetoothデバイスを検出します。

接続するデバイスのBluetooth画面に"XROUND FORGE NC"が表示されたら選択します。

選択したら"ペア設定する"を選択してください。ペアリングが完了すると、音声で"Connected"とお知らせします。

イヤホンのLEDランプが白くゆっくり点滅するとペアリング完了です。イヤホンを充電ケースから取り出せば、デバイスと接続された状態になっています。

4 操作のしかた

以下の説明は、出荷時の設定です。タッチパネルの操作動作は、専用アプリ"XROUND MyTune"でカスタマイズできます。

左耳

カウントダウンタイマー: 左のパネルを約1.5秒ロングタッチします。短いブザー音でお知らせしてから指を離し、カウントダウンが始まります。設定した時間が経過すると、同じ音でお知らせします。デフォルト設定は30秒です。カウントダウン時間を調整したい場合、アプリ"XROUND MyTune"で変更できます。

音量+: 左のタッチパネルを2回タップします。

音量-: 左のタッチパネルを3回タップします。

右耳

ノイズキャンセリング・外音取り込みモードの切替: 右のパネルを約1.5秒ロングタッチし、音声で"Noise cancelling"をお知らせするとともに、ノイズキャンセリングがオンになります。もう一度同じ動作を繰り返すと、音声で"Ambient sound"とお知らせすると外音取り込みモードになります。

音楽の再生/一時停止: タッチパネルを短く2回タップします。

音声アシスタント: タッチパネルを3回タップすると、音声アシスタントが起動します。

5 通話する

FORGE NCはスマートフォンでの通話に対応しています

電話を受ける 着信があったとき、タッチパネルを2回タップします。

電話を切る 通話の状態から、タッチパネルを2回タップします。

着信を拒否する 着信があったとき、タッチパネルを3回タップします。

マイクミュート MyTuneアプリの"操作設定を変更する"ページで設置可能です。

6 音声案内

Power on:電源オン
Pairing:ペアリング中です
Connected:接続しました
Pairing successful:ペアリングしました

Battery low:電池残量が少なくなりました
Power off:電源オフ
Call Rejected:着信拒否
Noise cancelling:ノイズキャンセリング
Ambient Sound:外音取り込みモード

7 工場出荷時の状態に戻す(リセット)

左右両側のイヤホンを充電ケースに収納し、充電ケースのファンクションキーを約10秒長押しします。イヤホンのLEDランプは白とオレンジが同時に点滅、ケースのインジケーターが6回点滅したら指を離し、イヤホンは工場出荷時の状態に戻ります。

※リセットするとき、充電ケースからイヤホンを取り出さないでください。

以下のようなとき、充電ケースの電池残量が表示されます。

8 充電する

イヤホンに充電する:イヤホンを充電ケースに収納するとイヤホンの充電がスタートします。充電する前に、本体とケースの端子部分を清掃してから入れてください。

充電ケースに充電する:充電ケースの充電端子を充電してください。

※FORGE NCのケースはQiワイヤレス充電に対応します。

充電ケースを開けたときイヤホンを充電ケースに収納したときType-Cケーブルで充電ケースを充電しているとき

※イヤホンを充電ケースに収納すると、自動的に電源オフになり充電がスタートします。このときイヤホンのLEDランプはオレンジ色に点灯し、イヤホンが充電中であることを示します。充電が完了すると消灯します。

※充電ケースの電池残量がなくなると、イヤホンの充電は行われません。充電中、ケースのインジケーターがゆっくり点滅します。充電が完了すると消灯します。

電池残量	インジケーター表示
1~30%	赤色
30~65%	オレンジ色
65~100%	白色

製品仕様

Bluetoothバージョン	Bluetooth® 5.2
出力	Bluetooth標準規格 Power Class 1
最大通信距離	15 m / 障害物なし: 80m
対応コーデック	SBC、AAC、aptX™、aptX™ adaptive
対応プロファイル	AVRCP1.6 / HSP1.2 / HFP1.7 / A2DP1.3.1
ドライバー規格	7mm複合チタンコートドライバー
再生周波数帯域	20 - 20,000 Hz
感度	100 dB

インピーダンス	16 Ω
マイク規格	4 * MEMS (片側 2 * MEMS)
再生時間	イヤホン本体:9時間 / 充電ケース含む :32時間 ※ノイズキャンセリング、AAC規格、音量50%でテスト
充電ケース規格	Type-C充電ポート ※Qiワイヤレス充電に対応
充電時間	1.5時間内にフル充電 ※15分充電で約1時間再生可能
防滴防塵等級	イヤホン本体IP67
内容物	FORGE NC 完全ワイヤレスイヤホン本体 * 1ペア 充電ケース * 1個 Type-C 充電ケーブル * 1本 低音強化イヤーピース * 3サイズ (S/M/L) コンフォートイヤーピース * 4サイズ (S/M/L/XL) イヤーフック * 4ペア (Null/S/M/L) クイックスタートガイド、取扱説明書

安全と操作上のご注意

イヤホンを長く安全にご使用いただくために、以下の事項をお守りください。

- イヤホンを投げたり落としたりしないでください。
- 湿気やホコリの多い場所、または51°C以上の高温の環境下では使用しないでください。
- 本イヤホンを大音量でご使用した場合には聴力を損なう恐れがあります。できる限り音量を控えめに調整していただくことをおすすめいたします。
- 交通安全のため、車やバイク、自転車の運転時には本イヤホンを使用しないでください。
- 鉄道の踏切、駅のプラットフォーム、横断歩道、工事現場などではイヤホンを使用しないでください。
- 柔らかい布または綿棒でお手入れしてください。
- 電池の寿命を維持するために、充電ケースは充電が完了したらケーブルを外してください。
- 充電は純正品または認証を受けた接続ケーブルで行ってください。
- イヤホンと付属品には小さな部品が使われています。誤って口に入れたりしないよう、お子さまの手の届くところに放置しないでください。
- Bluetooth通信は、以下環境下では干渉を受けやすくなりますのでご注意ください。
 - 近くに複数のWi-FiやBluetoothの電波が行き交う環境。
 - 空港、高速鉄道、地下鉄など電磁の干渉が比較的高い環境。

電池を安全にご利用いただくために

- CEマークの基準を満たす充電器で充電してください。
- 電池の液漏れや発熱、発火を防ぐため、電池を改造、分解したり、異物を混入したり、水または他の液体に浸したりしないでください。
- 本機器の電池は内蔵式のため着脱できません。回路の故障による発火や感電などの事故を防ぐため、電池部を分解、改造しないようにしてください。
- 電池の廃棄は、ご利用の地域のルールと説明に従ってください。

保証の内容および保証期間について

このたびはFORGE NC完全ワイヤレスイヤホンをご購入いただき誠にありがとうございます。XROUND Inc.では製品の材料および製造工程に万全を期しておりますが、何か問題がございましたら以下の記述をご参考ください。

保証期間はご購入の日またはお受け取りの日から起算して一年以内です。保証期間を超えた場合、法律上の保証期間も過ぎているものとみなします。

下記の状況によって引き起こされたいかなる瑕疵、故障または不具合は、いずれも弊社の責任・保証対象外となります。

- 誤った操作、乱用、人的過失等で生じた電子部品、機械、外観または各種部品の損傷。
- 不可抗力または自然、天災による損傷。
- 製造者の認証を受けていないメンテナンスセンターまたは人員による不適切な修理。

その他の注意事項

保証期間はご購入の日またはお受け取りの日から起算して一年以内です。ご購入または保証についての証明の添付を求められる場合があります。日本の販売代理業者以外の流通経路で本製品をご購入された場合、製品に関する品質保証や保守・修理についてのご質問は、お買い上げの取扱業者にご連絡ください。日本における販売代理業者に関する詳しい情報は公式ウェブサイトをご覧ください。

